





ПОДДЕРЖИВАЕМЫЕ МАРКИ АВТОМОБИЛЕЙ, КОДЫ И СОСТОЯНИЯ БЛОКА ПЕРЕКЛЮЧАТЕЛЕЙ SW1


Переключатели	Код	Марка автомобиля
---------------	-----	------------------


AUDI		
	1111	R8(с 2007г.)
	1411	A6(с 2005г.) Q7(с 2005г.) RS6(с 2005г.) S6(с 2005г.)
	1412	A4/S4(с 2008г.) A5/S5(с 2007г.) Q5(с 2008г.)
	1413	A3/S3(с 2003г.)
	1414	A8/S8(с 2003г.)
	1415	A4(с 2002г.)


BMW (с Keyless)		
	5111	1 (E87)(с 2004г.) 3 (E90)(с 2005г.) 5 (E60)(с 2003г.) 6 (E63/E64)(с 2005г.) X5 (E70)(с 2005г.) X6 (E71)(с 2008г.)
	5112	5 (E60)(с 2003г.) 7 (E65)(с 2005г.)

CADILLAC		
	4111	ESCALADE(с 2008г.)



CHEVROLET		
	1313	CRUZE(с 2009г.)
	1314	CAPTIVA(с 2007г.)
	4111	TAHOE(с 2008г.)

CHRYSLER		
	4311	300C(с 2005г.) GRAND VOYAGER (с 2008г.) PT Cruiser (с 2006г.) SEBRING (с 2007г.)

CITROEN		
	1711	(Комплектация 1) BERLINGO(с 2008г.) C2(с 2006г.) C3(с 2006г.) C3 PICASSO(с 2006г.) C5(с 2004г.) C4(с 2007г.) C4 PICASSO(с 2007г.) C8(с 2006г.) JUMPY3(с 2007г.)
	1712	JAMPER


DODGE		
	4311	AVANGER (с 2007г.) CALIBER (с 2006г.) DURANGO (с 2004г.) MAGNUM (с 2005г.) RAM (с 2008г.)


FIAT		
	1712	Ducato (с 2006г.)


FORD		
	1211	C-MAX(GHIA)(с 2003г.) C-MAX(с 2003г.) FOCUS2, 3(с 2005г.) KUGA(с 2008г.)
	1212	FIESTA(с 2006г.) FUSION(с 2006г.)
	1213	GALAXY(с 2006г.) MONDEO(с 2007г.) S-MAX(с 2007г.) TRANSIT(с 2007г.)
	1214	FIESTA(с 2009г.)
	1215	EXLORER


HONDA		
	2611	Pilot(с 2009г.)
	2612	Pilot(багажник с мотоприводом) (с 2004г.)
	2613	CITY(с 2009г.) CIVIC(с 2006г.) CR-V(с 2007г.) JAZZ(с 2009г.)
	2614	ACCORD(с 2009г.)

	5213	G (W463) Gelandewagen(с 2004г.)
	5214	A (W169)(с 2004г.) B (W245)(с 2005г.)

MITSUBISHI		
	2211	OUTLANDER(с 2007г.) LANCER(с 2008г.) ASX (с 2010г.)
	2212	PAJERO IV

NISSAN		
	2311	MURANO(с 2009г.) NAVARA(с 2006г.) PATHFINDER(с 2006г.) QASHQAI(с 2007г.) TIIDA(с 2008г.) X-TRAIL (с 2007г.)
	2312	TEANA(с 2008г.)

OPEL		
	1311	ASTRA H(с 2004г.) ZAFIRAB(с 2005г.)(не укомплектованы системой Open&Start)
	1312	CORSA D(с 2006г.) SIGNUM(с 2002г.) VECTRA C(с 2002г.)
	1313	ASTRA J (с 2010г.) INSIGNIA(с 2009г.)
	1314	ANTARA(с 2007г.)

PEUGEOT		
	1711	PARTNER(с 2008г.) EXPERT(с 2007г.) 308(с 2007г.) 607(Z9)(с 2005г.) 3008(с 2009г.)
	1712	207(с 2006г.) 307(с 2006г.) 308(с 2007г.) 3008(с 2009г.) 407(с 2006г.) 607(Z9)(с 2005г.) 807(с 2006г.) EXPERT(с 2007г.) PARTNER(с 2008г.)
	1713	BOXTER(с 2006г.)
	2211	4007(с 2007г.)

PORSCHE		
	1112	CAYENNE(с 2006г.)
<img alt="8-position switch diagram for Porsche Panamera"		